

CONNECTING COMPONENTS

Speaker Terminals — Use the color-coded wires (supplied) to connect each speaker to the appropriate terminal. For example, use the brown and black speaker wires to attach the subwoofer to the **SUB WOOFER** terminals.
Note: Be sure to connect the solid black wire to the black terminals, and the black-and-color striped wire to the color terminals.

DIGITAL OUT — If you have a digital audio device such as a MD or DAT recorder, use Toslink cable to connect it here

